

Kleinfunksprech D Antennae

The antennae and base should be black, or similar to blackened steel. Insert .040 inch styrene rod into the antennae base casting so that it extends below the bottom of the casting so that it can be mounted to the radio. Secure with thin CA. The antennae is designed for a slip fit so that it can be easily removed.

